


Item#	Part code	Description
1	BH7100-01	V-BLOCK
2	BH7100-02	PIN
3	BH7100-03	STEEL CABLE
4	BH7100-04	GEAR BOX
5	BH7100-05	ROLLER ASY-1
6	BH7100-06	ROLLER ASY-2
7	BH7100-07	RAM
8	BH7100-08	FOOT BASE
9	BH7100SG	SAFETY GRID ASSY (Optional)
10	BH720-22	PRESS PINS
11	BH720-23	PUNCHER ϕ 10
12	BH720-24	PUNCHER ϕ 12
13	BH720-25	PUNCHER ϕ 16
14	BH720-26	PUNCHER ϕ 18
15	BH720-27	PUNCHER ϕ 20
16	BH720-28	PUNCHER ϕ 22
17	BH720-29	PUNCHER ϕ 25
18	BH720-30	PUNCHER ϕ 30
19	BH720-31	ADAPTOR
20	BH7100-20	RUBBER SEAT
21	BH7100-21	TOOL TRAY
22	BH7100-22	FOOT PEDAL
23	BH7100-23	AIR INLET HORSE-S
24	BH7100-24	AIR INLET HORSE-L
25	BH7100A-25	PUMP ASSEMBLY
26	BH7100A-26	PUMP HANDLE
27	BH7100A-27	OIL TANK
28	BH7100-28	OIL HOSE-1
29	BH7100-29	OIL HOSE-2
30	BH7100-30	PRESSURE GAUGE
31	BH7100-31	OIL HOSE-3
32	BH7100-32	OIL HOSE-4
33	BH7100-33	OIL HOSE ASSY-5
34	BH7100-34	HANDLE
35	BH7100-35	SPIRAL BAR ASSY
36	BH7100-36	RAM SUPPORT PLATE
37	BH7100-37	ROLLING PIN ASSY
38	BH7100A-38	PUMP CASE
39	BH7100A-39	REROFIT PUMP KIT



BH7100A



www.bahco.com