


Item#	Part Code	Description
1	BH715-01	RAM ASSY
2	BH715-02	OIL HOSE
3	BH715-03	HOSE BASE ASSY
4	BH715-04	OIL HOSE
5	BH715-05	HANDLE
6	BH715-06	PUMP
7	BH715-07	FOOT BASE
8	BH715-08	TOOL TRAY
9	BH715-09	PIN
10	BH715-10	V-BLOCK
11	BH715-11	SCREW ASSY FOR RAM PLATE
12	BH715-12	GAUGE
13	BH715-13	PRESS PINS </td
14	BH720-23	PUNCHER Ø10
15	BH720-24	PUNCHER Ø12
16	BH720-25	PUNCHER Ø16
17	BH720-26	PUNCHER Ø18
18	BH720-27	PUNCHER Ø20
19	BH720-28	PUNCHER Ø22
20	BH720-31	ADAPTOR



BH715

Revision: 02

SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe.