
Part Code	Description
1 BBRBB12-01	PRESSURE GAUGE-
	MANOMETRE
	FUSE 6.3A-10PCS
BBRBB12-03	FUSE HOLDER
BBRBB12-04	PRESSURE REGULATOR
BBRBB12-05	SWITCH ON/OFF
BBRBB12-06	SWITCH CONTINUE/PULSE
BBRBB12-07	PCB
BBRBB12-08	INTERNAL 10L RESERVOIR+CAP
BBRBB12-09	CAP WITH AIR FILTER
BBRBB12-10	BRAKE FLUID OIL FILTER
BBRBB12-11	BATTEREY CABLES WITH CLAMPS
BBRBB12-12	CLAMPS
BBRBB12-13	1L BOTTLE+TUBE+NIPPLE
BBRBB12-14	TUBE+NIPPLE
BBRBB12-15	FEMALE COUPLING TO ADAPTER
BBRBB12-16	FEMALE COUPLING COMPLETE
BBRBB12-17	PUMP WITH CONNECTORS
BBRBB12-18	2 WHEELS + CAPS
BBRBB12-19	ADAPTOR+GASKET+TUBE E20PW
BBRBB12-20	E20PW ADAPTOR+GASKET
BBRBB12-21	RUBBER GASKET-10PCS
BBRBB12-22	LATERAL PANEL (1 UNIT)
BBRBB12-17K	PUMP REPAIR KIT
	BBRBB12-04 BBRBB12-05 BBRBB12-06 BBRBB12-07 BBRBB12-07 BBRBB12-09 BBRBB12-10 BBRBB12-10 BBRBB12-11 BBRBB12-12 BBRBB12-13 BBRBB12-14 BBRBB12-15 BBRBB12-15 BBRBB12-16 BBRBB12-17 BBRBB12-17 BBRBB12-19 BBRBB12-19 BBRBB12-19



BBRBB12

Revision: 01



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe.