

## Video User manual

<https://youtu.be/TsAJzUsLRDQ?t=1>



## INDEX

- 1-General View (00:08 min)
- 2-Battery Installation (01:17 min)
- 3-115VAC-230VAC / 50Hz-60Hz Connection (01:48 min)
- 4-Lock-Prog Switch (02:06 min) 5-PC USB Connection (02:18 min)
- 6-Torque Preset (02:40 min) 7-Torque Preset Lock (03:24 min)
- 8-Torque Preset Verification (03:36 min)
- 9-Power Up (03:45 min)
- 10-"LOCK" and "PROG" Positions Switch (04:01 min)
- 11-Adding a Wrench or Wrenches(04:19 min)
- 12-Normal Operation (04:57 min)
- 13-Clearing a Wrench (05:33 min)
- 14-Buzzer Volume (05:50 min)
- 15-Software Installation(06:11 min)
- 16-Software configuration(08:39 min)
- 17-Checking communication (09:01 min)
- 18-Programmable Tool Functions (09:47 min)
- 19-Programmable Box Functions (12:25 min)
- 20-Peripherals - Relays Output Signals (17:26 min)
- 21-Peripherals - Latching Reset (19:55 min)