


Nº	CODE	DESCRIPTION
1	BH15000B-01	REAR WHEEL ASSY (1 UNIT)
2	BH15000B-02	FRONT WHEEL ASSY (1 UNIT)
3	BH15000B-03	PUMP ASSY
4	BH15000B-04	METAL SADDLE
5	BH15000B-05	SPRING
6	BH15000B-06	TOOL TRAY
7	BH15000B-07	FOOT PEDAL ASSY
8	BH15000B-08	HANDLE ASSY
9	BH15000B-09	YOKE ASSY



BH15000B

Revision: 00

SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe

20092022